

MP CARRIER

MOUNTING TEMPLATE

This template may be printed and used to check for proper hole spacing. If your web browser does not print the template to scale you will need to download the file and open it with Acrobat Reader then choose "actual size" as your print option.

